

TO BEGIN INSTALLATION...

- O1. Loosen locknut on your shocks lower eyelet.
- O2. Unscrew the original standard length eyelet from the shock.
- O3. Remove the locknut from the original eyelet and install it onto the new Kraus + length eyelet.

NOTE: Make sure when installing the new Kraus + length eyelet that the threads are coated with Blue Locktite 243, at least 1/2" length of thread is installed into the shock body, and the locknut is tightened back in place.

- O4. Repeat for both shocks making sure eyelets are installed to equal length on both shocks.