

TO BEGIN INSTALLATION...

01. **Prior to installing forks** into the triple trees, slide the OEM “cowbell” fork tube cover over the fork legs and slide to the bottom.
02. Apply blue Loctite 243 to 1/4-20 x1 screws and loosely assemble the clamp halves. Make sure there is an even gap on both sides. Install on fork.
03. Slide the adapter down to the top of the “cowbell” and install two 10/24 x 3/8 screws. Torque to 36 in. lbs.
04. Slide “cowbell” assembly to the top of the fork.
05. **Starting** with the **outboard** side, use a 3/16 long ball allen wrench to tighten the two 1/4-20 x1 screws.
06. Installation is complete. Enjoy your ride.